



# TW-25S & TW-35S Installation Guide


## Flush Mount Assembly




## Flush Mount Installation



## Angle Mount Assembly & Installation



## Surface Mount Assembly & Installation



**EARTHQUAKE**  
EARTHQUAKE  
The Sound That Will Move You

# TW-25S & TW-35S Installation Guide

## Parameters for TW-25S

**Re:** 2.87 ohm

**Fs:** 1499Hz

**Qts:** 1.27

**Qes:** 4.41

**Qms:** 1.79

**Le:** 0.031mH (10KHz)

## Parameters for TW-35S

**Re:** 3.55 ohm

**Fs:** 1049Hz

**Qts:** 1.04

**Qes:** 1.31

**Qms:** 4.95

**Le:** 0.059mH (10KHz)



**TW-25S**



**TW-35S**

**EARTHQUAKE  
EARTHQUAKE**  
The Sound That Will Move You